

Installation Instructions

Residential/ Commercial Sub-Floors

Step 1 – Roll the material over the joists



SIMPLE OVER-JOIST INSTALLATION *AFTER* SUB-FLOOR CONSTRUCTION & SERVICES INSTALLATION

Step 2 – Align oval shaped holes to joists



PATENTED OVAL SHAPED HOLES ACROSS THERMO FLOOR ALIGN WITH STANDARD JOIST SPACING

Step 3 – Apply adhesive bead for flooring



84% CONTINUOUS 5mm ADHESIVE BEAD FOR FLOORING (COMPLIANCE)

Step 4 – Install your sheet flooring as normal



INSTALL IN-LINE WITH & SAME TIME AS FLOOR
➤ COMPLIANT, NON SQUEAKY FLOORING
➤ NO DAMAGE TO INSULATION
➤ NO PERFORMANCE LOSS
➤ SAFE WORKING PLATFORM + GROUND ACCESS



CONTROLLED LOCATION EVERY TIME
➤ GUARANTEED PUBLISHED R-VALUES
➤ CONTINUOUS VAPOR BARRIER
➤ INSTALL FLOORING AS NORMAL